


Adolf Schuch GmbH

Lichttechnische Spezialfabrik Mainzer Str. 172, D-67547 Worms am Rhein Postfach (P.B.) 2145, D-67511 Worms

Phone: +49 6241/4091-0 Telefax: +49 6241/4091- 29 Internet: www.schuch.de E-Mail: info@schuch.de



- Operating Instructions

Explosion-proof LED-Light Fitting of series

e865





The safety of people and equipment in hazardous areas depends on the observance of all safety standards. Exact knowledge about all applicable regulations and standards is mandatory for installation maintenance and repair of explosion proof equipment, especially

- the determinations of IEC/EN 60079-14 and IEC/EN 60079-17 for maintenance of explosion-proof appliances
- the generally accepted rules of the technical side
- the national rules for prevention of accidents and for safety standards
- the safety instructions of these operating instructions
- the characteristic data on the type plate and the instruction plates

1. Safety Instructions

- Mounting and installation must be done in accordance with the respective regulations.
- The light fitting must be protected against overvoltage, overcurrent, short circuits and other electrical failures.
- The light fitting must be operated in an undamaged condition only.
- The light fitting may only be opened if it has been disconnected from the mains supply completely.
- The non-stationary use of the light fitting as well as any other inappropriate usage is prohibited.
- The operation of the light fitting is allowed within its assessment thresholds only.
- In regard to the minimum and maximum admissible ambient temperature potential sources of cold and heat (e.g. direct heat or solar radiation, cooling units) have to be considered.
- If the light fitting is to be subject to a special application that is influenced chemically, mechanically, thermically or electrically or if the light fitting will be subject to any kind of vibrations, it is highly recommended to consult the Adolf Schuch GmbH before starting the installation.
- Every structural modification will cause dangerous situations and consequently the certification of this light fitting will be null and void. So it is not allowed to drill through the housing for installation purposes.
- Caution Risk of electrostatic discharge!
 Fitting to be cleaned with damp cloth only!
- In areas with risk of accidental electrostatic charge (e.g. by passing by) the light fitting must be protected by appropriate measures.
- The light fitting is not allowed to be installed in process areas where strong electrical fields may occur (i.e. HV Sparkling Electrodes or Particle Streams). Reason is to avoid any electrostatic charge of the light fitting itself.
- Replace damaged explosion-proof parts by original spare parts from the Adolf Schuch GmbH only.
- LED-reflector with mounted LED-modules and Electronic control gear of this light fitting must be replaced by A. Schuch GmbH, by a service technician who is instructed from Schuch or by any other person with equivalent qualification only.
 It is not allowed to replace the individual LED-modules of this light fitting.

2. Operating Advice

- Because of the chemical resistance use only a damp cloth for cleaning the light fitting. If necessary
 with a mild and solvent-free cleaning agent.
- Against penetration of humidity into the light fitting a special explosion-proof breathing gland is often
 quite effective. It is allowed to use a breathing gland which is released by the Adolf Schuch GmbH
 only. If using a breathing gland please observe the general informations of it's operation
 instructions.
- A through wiring system in explosion-proof light fittings can also be installed at a later stage by using original components of the Adolf Schuch GmbH only.
- Any application of the light fitting that is incorrect or even forbidden will lead to the fact that the manufacturer's warranty is lost.
- Opening the LED compartment is allowed for repair work only.
- LED are sensitive electronic components. Please ensure that the LED are protected against mechanical and electrostatic attacks whenever the light fitting is open. For this reason the LED must not be touched either.
- Due to harmful gases and other corrosive substances (e.g. ammoniac- sulphur-, or chlorine compounds) it may come to damages of the LEDs. Depending on the substance, the concentration, the temperature and the dwell time, damages up to total black-out are possible. This may occur also to fittings with high degree of protection. The suitability of the light fitting for the respective application can only be checked by running a test at site.

Due to a high inrush current when switching on the light fitting, the number of light fittings which can be connected to a single fused circuit is limited (Possible number of light fittings per circuit breaker see section 3, Technical Data).

 All DALI dimmable light fittings have two additional terminals marked "DA". Lines to the control terminals must be mains voltage proof.

3. Technical Data

Series: e865

Explosion-proof LED-Light Fitting for operating in hazardous areas of

zones 1, 2, 21 and 22.

Explosion protection:

Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection:
Explosion protection protection:
Explosion protection prote

(a) II 2 G Ex db eb mb op is q IIC T4 Gb (with isolating switch)

II 2 G Ex eb mb op is q IIC T4 Gb (with Schuch monitoring module)
 II 2 G Ex db eb mb op is q IIC T4 Gb (with isolating switch and Schuch

monitoring module)

(a) II 2 G Ex eb ib mb op is q IIC T4 Gb (with CEAG/Eaton monitoring

module)

© II 2 G Ex db eb ib mb op is q IIC T4 Gb (with isolating switch and CEAG/

Eaton monitoring module)

Certification: IBExU 16 ATEX 1008

IECEx IBE16.0010

Rated voltage: 220...250 V AC; 50 ... 60 Hz (standard version)

220...240 V AC; 50 ... 60 Hz (with Schuch moniotoring module) 220...250 V AC; 50 ... 60 Hz (with CEAG/Eaton monitoring module)

176...275 V DC (standard version)

180...264 V DC (with Schuch monitoring module) 176...275 V DC (with CEAG/Eaton monitoring module)

Isolation class:

Ingress protection: IP66 (When using an Ex-breathing gland see section 2)

Ambient temperature: -30 °C ... +50 °C resp. +55 °C (Standard versions)

Special versions and versions for higher ambient temperatures see type

plate

Power consumption: The power consumption of the LED is dependent on production fluctuations

as well as on the service temperature.

This is why just reference values can be given as follows:

e865. 12L42: 34 W e865. 12L60: 47 W e865. 12L85: 65 W

Cable entry: Cable gland with thread size M25 x 1.5

(if supplied) Sealing range: 7 - 17 mm (for 10 - 17 mm remove the small sealing ring)

Torques: Connection thread 3 Nm; Pressing screw 2 Nm

Torque of locking screw: 5 Nm

See information label on the front page when having special versions!

Locking: Clamp lockings (to be opened by hand) as well as one safety closure at

each side (to be opened with a suitable screw driver)

Connection per terminal: Clamping range: 2 x 1 - 4 mm² max.

Ampacity: 16 A max.

Required stripping length: 10 - 11 mm

See information label on the front page when having special versions!

Operation position: in any direction - except upwards light output


Possible number of light fittings per circuit

breaker:

	Type B 10 A	Type B 16 A	Type C 10 A	Type C 16 A
e865 12L	8	12	13	22

Through wiring / Looping:

Potential limitations to be considered (see type plate)




4. Installation



- ➤ The safety of this light fitting is only guaranteed as long as it is operated within its assessment threshold. Installation and maintenance must be done in accordance with the respective regulations!
- The installation of explosion-proof light fittings must be done by Ex-skilled electricians only!
- In regard to the minimum and maximum admissible ambient temperature potential sources of cold and heat (e.g. direct heat or solar radiation, cooling units) have to be considered!
- ➤ The application of this light fitting in an explosive dust atmosphere is depending on the properties of the surrounding dust. Please ensure that there will be an adequate difference between the maximum surface temperature of the fitting and the glowing and the ignition temperature of the respective dust!
- ➤ The light fitting must be mounted in the instructed operation position (see section 3, Technical Data)!

4.1 How to open the light fitting



- remove the diffuser with the included reflector.

4.2 Electrical connection

- screw the explosion-proof cable glands and explosion-proof locking screw supplied with the fitting
 into the borings of the housing by using the lock nuts (Torques see section 3, Technical Data).
- After mounting the light fitting housing insert the connection cable through the explosion-proof cable gland. An inlaid dust protective disc, if existing, must be removed before.
- Fasten the pressing screw of the explosion-proof cable gland (Torque see section 3, Technical Data).



- For higher ambient temperatures there is only restricted respectively no possibility for looping facility or through-wiring-system. Please follow the information on the type label of the fitting.
- Appropriate measures (e.g. pull relief clips) must be taken to protect the connection cable which is inserted through the cable entry from tractive forces and twist!
- ➤ The diameter of the connection cable must correspond to the sealing range of the explosion-proof cable gland (see section 3, Technical Data)!
- Cable entries, which are not used, must be closed with the enclosed closure plug (see section 3, Technical Data)! An inlaid dust protective disc, if existing, must be removed before.
- ▶ The conductors must not be damaged when skinning resp. stripping the cable!
- When stripping the cable special attention needs to be paid to the correct length of the conductor end sections (see section 3, Technical Data)!

Connect the conductors to the right terminals as per marking.



▶ It is important to ensure that the bare conductor is fully inserted into the terminal and that no cable insulation is clamped!

4.3 Replacing LED and electronic gear

LED-reflector with mounted LED-modules and Electronic control gear of this light fitting must be replaced by A. Schuch GmbH, by a service technician who is instructed from Schuch or by any other person with equivalent qualification only. The replacement requires prior consultation of the A. Schuch GmbH

It is not allowed to replace the individual LED-modules of this light fitting.

4.4 How to close the light fitting

- Join diffuser with included reflector and housing together.
- Hook the clamp lockings into the diffuser and fix it.
- After closing the light fitting take care that the whole gasket is effective.


5. Commissioning

Before commissioning this explosion-proof lighting fitting please check and ensure that:

- the light fitting has been installed according to the regulations and in the allowed operating position.
- the explosion-proof cable glands resp. explosion-proof locking screws are securely fixed in the housing (Torques see section 3, Technical Data).
- the pressing screw of every explosion-proof cable gland is tightened with the required torque (Torques see section 3, Technical Data).
- the connection cable has been firmly installed and is not subject to any tension whatsoever.
- the bare conductor is fully inserted into the terminal and that no cable insulation is clamped.
- the light fitting is closed correctly.
- all gaskets are effective.
- the light fitting is not damaged whatsoever.

5.1 Isolation measurement


For measuring the isolating resistance the test voltage must be put on between the outer conductor and the earth conductor or between the neutral conductor and the earth conductor only.




After finishing the isolation test the conductor between the mains and the light fitting must be reconnected safely. Before starting operation the connection of the neutral conductor must be safe for avoiding any damage whatsoever of the electronic control gear caused by any inadmissible excess-voltage in case of an unbalanced mains load. (see section 5.2)


5.2 Electronic gear in 3-phase-operation

The diagram shows the wiring for light fittings or light fitting groups in 3-phase circuits and with a common neutral conductor N.









If the common neutral conductor is interrupted and voltage is present, then light fittings or groups of light fittings may be exposed to unacceptably high voltages and consequently the electronic gear may be destroyed.

Maintenance

Explosion-proof light fittings need regular maintenance according to the national rules of the country they are installed. Especially components which are important for the Explosion Category have to be carefully checked. Therefore it must to be checked very carefully:

- glass, housing and gaskets for any kind of damages.
- the correct installation and tightness of explosion-proof cable glands and explosion-proof locking screws (Torques see section 3, Technical Data).
- all parts of plastic inside the light fitting to attend to colour change, deformation and damaging.
- the tight fit of the conductor and the condition of the cable insulation.
- that the light fitting is closed correctly and the gasket is effective.

6.1 Cleaning the light fitting



▶ At the plastic parts of the light fitting there is a danger of ignition due to electrostatic charging! For cleaning the housing and cover outside and inside and for cleaning internal plastic components use only cold or lukewarm water (if necessary with a mild cleaning agent) together with a viscose sponge or a soft fibrous-free cloth!

Pay attention to the following in case of application of this light fitting in dusty atmospheres: Dust deposits have got thermal insulation characteristic features. It is necessary to clean the fitting from dust regularly. In case the dust layer may be higher than 5 mm it must be ensured that the surface temperature of the light fitting does not exceed the maximum permissible surface temperature of the specific dust considering the thickness of the dust layer. The dust layer must not exceed 50 mm at any time.

6.2 Repair- and maintenance works



- ➤ For applications in dusty atmospheres the light fitting must be cleaned before opening!
- ► Ensure that there will be no dust getting into the light fitting while it is open!
- ➤ Replace damaged explosion-proof parts by original spare parts from the Adolf Schuch GmbH only!



EU-Konformitätserklärung EU-Declaration of Conformity Déclaration UE de Conformité

Déclaration UE de Conformité **EU-Declaration of Conformity** EU-Konformitätserklärung

SCHUCH

e 865. 12L...ZB; e 865. 12L...-J; e 865. 12L...-C

Bezeichnung des Betriebsmittels Beschreibung des Betriebsmittels

Name of product Nom du produit

Explosionsgeschützte Leuchte

Explosion-proof luminaire IBEXU 16 ATEX 1008



Name of product	e 865, 12L
Beschreibung des Betriebsmittels	Explosionsgeschützte Leuchte
Description of product	Explosion-proof luminaire
Description du produit	Luminaire antidéflagrant
EG/EU-Baumusterprüfbescheinigung	IBEXU 16 ATEX 1008
EC/EU type examination certificate	IBExU - Institut für Sicherheitstechnik GmbH (0637)
Attestation d'examen CE/UE de type	Fuchsmühlenweg 7, D-09599 Freiberg
Relevante EU-Richtlinie	2014/34/EU ATEX-Richtlinie (Abl. L96)
Relevant EU directive	2014/34/EU ATEX Directive (OJ L96)
Directive UE importante	2014/34/UE Directive ATEX (JOUE L96)
Angewandte Normen	EN 60079-0:2012+A11:2013, EN 60079-7:2015, EN 60079-31:2014,
Applied standards	EN 60079-28:2015
Normes appliquées	EN 60598-1:2015, EN 60598-2-1:1989
Relevante EU-Richtlinie	2014/30/EU EMV-Richtlinie (Abl. L96)
Relevant EU directive	2014/30/EU Electromagnetic compatibility (OJ L96)
Directive UE importante	2014/30/UE Compatibilité électromagnétique (JOUE L96)
Angewandte Normen	EN 55015:2016, EN 61000-3-2:2014, EN 61000-3-3:2013,
Applied standards	EN 61547:2009
Normes appliquées	
Relevante EU-Richtlinie	2011/65/EU RoHS-Richtlinie (Abl. L174)
Relevant EU directive	2011/65/EU RoHS-Directive (OJ L174)
Directive UE importante	2011/65/UE Directive ROHS (JOUE L174)
Angewandte Normen	EN 50581:2012
Applied standards	
Normes appliquées	
Relevante EG-Richtlinie	2009/125/EG ErP-Richtlinie (Abl. L285)
Relevant EC directive	2009/125/EC ErP-Directive (OJ L285)
Directive CE importante	2009/125/CE Directive ErP (JOUE L285)
Angewandte Verordnung	1194/2012, 1428/2015
Applied regulation	

EN 60079-0:2012+A11:2013, EN 60079-7:2015, EN 60079-31:2014,

2014/34/UE Directive ATEX (JOUE L96 2014/34/EU ATEX Directive (OJ L96)

IBExU - Institut für Sicherheitstechnik GmbH (0637)

EG/EU-Baumusterprüfbescheinigung

Description of product Description du produit

Attestation d'examen CE/UE de type EC/EU type examination certificate

Relevante EU-Richtlinie

Angewandte Normen

Directive UE importante

Relevant EU directive

Fuchsmühlenweg 7, D-09599 Freiberg 2014/34/EU ATEX-Richtlinie (Abl. 196)

EN 60598-1:2015, EN 60598-2-1:1989, EN 60598-2-22:2014

EN 60079-28:2015

EN 55015:2016, EN 61000-3-2:2014, EN 61000-3-3:2013, 2014/30/UE Compatibilité électromagnétique (JOUE L96)

EN 61547:2009

2011/65/EU RoHS-Richtlinie (Abl. L174) 2011/65/EU RoHS-Directive (OJ L174) 2011/65/UE Directive RoHS (JOUE L174)

Relevante EU-Richtlinie

Normes appliquées

EN 50581:2012

Angewandte Normen

Applied standards

Directive UE importante

Relevant EU directive

2009/125/EG ErP-Richtlinie (Abl. L285) 2009/125/EC ErP-Directive (OJ L285) 2009/125/CE Directive ErP (JOUE L285)

1194/2012, 1428/2015

Angewandte Verordnung

Règlement applique

Directive CE importante

Relevant EC directive

Relevante EG-Richtlinie

2014/30/EU Electromagnetic compatibility (OJ L96)

2014/30/EU EMV-Richtlinie (Abl. 196)

Relevante EU-Richtlinie Angewandte Normen

Normes appliquées

Applied standards

Directive UE importante

Relevant EU directive

Hiermit erklären wir in alleiniger Verantwortung, dass das oben aufgeführte Produkt mit den Anforderungen der angegebenen Richtlinien und Normen übereinstimmt.

We hereby declare in our sole responsibility that the product above complies with the requirements of the specified directives and standards.

Nous déclarons de notre seule responsabilité que le produit mentionné ci-dessus est conforme aux exigences des directives et des normes indiquées.

Adolf Schuch GmbH - Mainzer Str. 172, 67547 Worms, GERMANY



Worms, 02.05.2018

Ort und Datum Place and date Lieu et date

Directeur de technique



Chef du dept.assurance de qualité

Directeur de technique Technischer Leiter 8 Technical Director

Nous déclarons de notre seule responsabilité que le produit mentionné ci-dessus est conforme aux exigences

Adolf Schuch GmbH - Mainzer Str. 172, 67547 Worms, GERMANY

des directives et des normes indiquées.

specified directives and standards.

Hiermit erklären wir in alleiniger Verantwortung, dass das oben aufgeführte Produkt mit den Anforderungen We hereby declare in our sole responsibility that the product above complies with the requirements of the

der angegebenen Richtlinien und Normen übereinstimmt.

Worms, 02.05.2018 Ort und Datum Place and date Lieu et date

Head of Quality Management Dept Leiter Qualitätsmanagement Chef du dept.assurance de qualité

IBExU 16 ATEX 1008-02 Teil/part/partie A/SB-00